



Master-Grip Double Wire Clamp, screw-fitting

Special clamp for fastening light and medium-weight, right-handed spiral hoses such as Flamex B-se, Flamex B-F se, Master-PUR Trivolution, Master-PUR Food, Master-PVC and Master-SANTO

Product Details

Construction / Material

- Specification of the connection solution: high closing force, tension-resistant and tight connection due to special double-wire system
- Clamp Design: wire clamp
- Material of the clamp: stainless steel 1.4301, material grade W4

Properties

- Chemical Properties: microbe-resistant
- Other: easy to assemble

Operating Temperature

Delivery Information

Application Areas

Customizing Options

Article Variants

Article number	DN of the hose mm	Type	Clamping range mm
002193	32	for Master-PUR L, H and HX in DN 32	31 - 37
002194	40	for Master-PUR L in DN 38 - DN 45, Master-PUR H and HX in DN 40	38 - 46

Article number	DN of the hose mm	Type	Clamping range mm
002195	50	for Master-PUR L in DN 55 - 60, Master-PUR H and HX in DN 51 - 55	51 - 61
002196	60	for Master-PUR L and H in DN 65 - 70, Master-PUR HX in DN 60 - 65	63 - 73
002197	80	for Master-PUR L in DN 80, Master-PUR H and HX in DN 75 - 80	77 - 86
002198	90	for Master-PUR L, H and HX in DN 90	83 - 96
002199	100	for Master-PUR L, H and HX in DN 102	90 - 110
002200	110	for Master-PUR L, H and HX in DN 110 - 115	101 - 121
002201	120	for Master-PUR L in DN 127 - 130, Master-PUR H and HX in DN 120 - 130	119 - 135
002202	150	for Master-PUR L, H and HX in DN 152	146 - 160
002203	160	for Master-PUR L, H and HX in DN 160	154 - 170
002204	170	for Master-PUR L in DN 170 - 180, Master-PUR H and HX in DN 170 - 175	167 - 182
002205	200	for Master-PUR L, H and HX in DN 203	197 - 217
002206	225	for Master-PUR L, H and HX in DN 225	220 - 240
002208	250	for Master-PUR L, H and HX in DN 250	246 - 266
011374	20	for Master-PUR L, H and HX in DN 20	20 - 32

Subject to technical changes and colour deviations

Delivery Variants

Available in other lengths, other nominal diameters, with customer-specific customer-specific imprint.

Disposal instructions

After use, the product must be disposed of in accordance with the legal regulations applicable in the user's region (in Germany in accordance with the applicable Waste Catalogue Ordinance (AVV)).

Individual consultation

We offer consultation by phone:
+49 209 97077-112

Product requests via
[masterflex.de/en](https://www.masterflex.de/en)

Address Headquarters

Masterflex SE
Willy-Brandt-Allee 300
45981 Gelsenkirchen

