Ø30 ARN/ARNS Series Mono-lever Switches

Single lever offers up to four directions of control

- Mono-lever switches operate in four directions using a single lever.
 Switch contacts are actuated in the direction in which the lever is pushed, enabling quick and accurate control in any desired direction.
 Ideal for machine tools and industrial machines. The lever action can be maintained or spring-returned in any combination.
- Also available with interlock mechanism to prevent inadvertent actuation.







· See website for details on approvals and standards.



Contact Ratings by Utilization Category

Rated Insulation	on Voltage		600V						
Rated Continuo	ous Current				10)A			
Operational Vo	Itage		24V	48V	50V	110V	220V	440V	
	AC	AC-12 Control of resistive loads and solid state loads	10A	_	10A	10A	6A	2A	
Operational	50/60 Hz	AC-15 Control of electromagnetic loads (> 72 VA)	10A	_	7A	5A	3A	1A	
Current	DC	DC-12 Control of resistive loads and solid state loads	10A	5A	_	2.2A	1.1A	_	
	DC	DC-13 Control of electromagnets	4A	2A	_	1.1A	0.6A	_	

Note: The operational current represents the classification by making and breaking currents (IEC 60947-5-1).


Specifications

Contact Configuration	Double-break slow action Each contact block contains two independent contacts (2NO, 1NO-1NC, 2NC) Up to four contact blocks can be mounted
Operating Temperature	−25 to +50°C (no freezing)
Storage Temperature	-35 to +80°C (no freezing)
Operating Humidity	45 to 85% RH (no condensation)
Insulation Resistance	100 MΩ minimum (500V DC megger)
Dielectric Strength	Between live and dead parts: 2,500V AC, 1 minute
Mechanical Life	500,000 operations minimum
Electrical Life	(Interlocking: 250,000 operations minimum)
Lever Knob	Black
Weight (approx.)	276g (ARN4-1111-20202020)

BR Contact Block

The contact block is made of nylon resin. Each contact block contains two pairs of double-break silver contacts. There are three types as shown in the diagram below and up to four contact blocks can be mounted in any direction.

A wide variety of circuits allows diverse combinations of control.





Control Mechanism

When the operator lever is pushed to about 30° in each direction from the neutral position, the contact in that direction activates. The lever can operate in two, three, or four directions, and combinations of maintained or spring-return from any position are possible.

APEM

Switches &

Control Boxes

Emergency Stop Switches Enabling Switches

Safety Products

Explosion Proof

Terminal Blocks

Relays & Sockets

Circuit

Protectors

Power Supplies

LED Illumination

Operator Interfaces

Sensors

AUTO-ID

Flush Silhouette

ø16

ø22

Miniature

Pilot Lights

TWN

TWND

ARN

CS

Control Boxes Emergency Stop Switches Enabling Switches Safety Products **Explosion Proof** Terminal Blocks Relays & Sockets Circuit

Protectors

Power Supplies

LED Illumination

Flush Silhouette

ø16

ø22

Miniature

Pilot Lights

TWN

TWND

CS

Controllers


Operator Interfaces Sensors AUTO-ID

Mono-lever Switches

		Operator	Number of Contact Blocks	Part No. (Ordering Part No.)	Package Quantity
	ARN (Long Lever)		1 Block	ARN1-3-4B	
	(Long Lover)		2 Block	ARN2-3-4B	
			3 Block	ARN3-3-4B	
			4 Block	ARN4-3-4B	
	ARNS (Short Lever)		1 Block	ARNS1-3-4B	
	(SHOIT LEVEL)		2 Block	ARNS2-3-4B	1
			3 Block	ARNS3-3-4B	'
			4 Block	ARNS4-3-4B	
	ARNL (Interlocking)		1 Block	ARNL1-3-4B	
	(intoriooking)		2 Block	ARNL2-3-4B	
			3 Block	ARNL3-3-4B	
		The operator lever is locked only in the center position.	4 Block	ARNL4-3-4B	


Specify Contact Configuration from the table below in place of 3 and 4. Terminal covers are ordered separately.

Dimensions




Minimum horizontal/vertical mounting centers: 110

ARNS (Short Lever)




Minimum horizontal/vertical mounting centers: 70


ARNL (Interlocking)



Minimum horizontal/vertical mounting centers: 110

Lever Operator Position





Panel Cut-Out



Ordering Information


When ordering, specify items ① to ⑤ according to the following example.



① Model	② No. of Contact Blocks	3 Lever Action	4 Contact Arrangement	⑤ Lever Knob Color
ARN ARNS ARNL	1: 1 block 2: 2 blocks 3: 3 blocks 4: 4 blocks	Order of Entry: Up→Right→ Down→Left 1: Maintained 2: Spring return 0: Blocked	Order of Entry: Up→Right→ Down→Left 10: 1NO 01: 1NC 11: 1NO-1NC 20: 2NO 02: 2NC 00: Blocked	B: black

- To calculate the number of contact blocks required, add the number of NO and NC contacts on each pair of adjoining positions (up + right, right + down, down + left, and left + up). The largest of the four sums is the number of contact blocks required. Up to four contact blocks can be mounted.
- . Specify the same number of contacts for the contact blocks of opposing corner (up-down, right-left), except for the blocked direction.

Mono-Lever with Terminal Cover



		Dir	ection of L	ion			
osition		<u> </u>		,/pe			
Contact Block Position	Terminal No.	Terminal No.	Contact Block Type				
පි	<u>1</u>	1	0	1	2	Te	පි
1	1	NO	_	_	_	2	BR-2E
'	3	_	_	NC	_	4	DN-ZL
2	5	_	NO *	_	_	6	BR-1E
-	7	_	_	_	NO	8	DN-1E
3	9	NO	_	_	_	10	BR-2E
3	11	_	_	NC	_	12	DN-ZE
4	13	_	NC *	_	_	14	BR-3E
4	15	_	_	_	NC	16	DU-9E

- *: Contacts marked with * do not operate.
- . When UL and CSA markings are required on the mono-lever switch, specify as shown below.

[Example] ARN4-1012-20000211B-U



Accessories and Maintenance Parts

Shape	Specification	Part No.	Ordering No.	Package Quantity	Description
Nameplate	70 →	MLO	MLO	1	Chrome-plated brass
материие	0300	MLO	MLOPN10	10	(matte surface)
Terminal Cover	38	ARN-VL2	ARN-VL2	1	Terminal covers are ordered separately. When ordering, specify the Part No. and the required quantity. Order 2 pieces for each contact block.
	0	BR-1E	BR-1E	1	2NO contact
Contact Block (BR)		BR-2E	BR-2E	1	1NO-1NC contact
		BR-3E	BR-3E	1	2NC contact
D.II		ARN-BL	ARN-BL		For ARN/ARNS (Locking ring not included)
Bellows		ARN-BL-1	ARN-BL-1	1	For ARN/ARNS (Locking ring included)
Bellows		ARNL-BL	ARNL-BL	1	For ARNL
(Interlocking)				·	(Locking ring not included)
Knob	•	ARNB-③	ARNB-③	1	Specify a color code in place of ①. B (black), G (green), R (red) For ARN/ARNS

Control Boxes Emergency Stop Switches Enabling Switches Safety Products **Explosion Proof** Terminal Blocks Relays & Sockets Circuit Protectors Power Supplies LED Illumination Controllers Operator Interfaces Sensors AUTO-ID Flush Silhouette ø16 ø22 Miniature Pilot Lights

TWND

ARN

CS

Ø30/Ø25 CS Series Cam Switches

71 standard circuits to choose from

- · Wide variety of heavy-duty oiltight cam switches
- Operators available up to 12 positions
- Contact blocks rated at 600V, 10A
- Ideal for ammeter/voltmeter applications
- UL listed and CSA approved



APEM

Stop Switches

Power Supplies

LED Illumination Controllers Operator Interfaces Sensors AUTO-ID

Enabling Switches Safety Products **Explosion Proof** Terminal Blocks Relays & Sockets Circuit Protectors





• See website for details on approvals and standards.



Specifications and Ratings

Contact Ratings by Utilization Category

Rated Insulation	n Voltage			600V					
Rated Continuo	us Current			10A					
Operational Volt	tage			24V	110V	220V	440V		
	AC	AC-12	-12 Control of resistive loads and solid state loads		10A	6A	2A		
Operational	50/60 Hz	AC-15	Control of electromagnetic loads (> 72 VA)	_	5A	3A	1A		
Current	DC	DC-12	Control of resistive loads and solid state loads	8A	3A	1A	0.4A		
	DC	DC-13	Control of electromagnets	5A	1.2A	0.45A	0.2A		

Note: The operational current represents the classification by making and breaking currents (IEC 60947-5-1).

Flush Silhouette

ø16 ø22

Miniature

Pilot Lights

TWN

ARN

Specifications

Contact Configuration	Double-break slow action contacts Two contacts in one deck Up to 6 decks available (Spring-return: Up to 3 decks)						
Operation	Maintained	Spring return					
Angle	30°, 45°, 60°, 90°	45°					
Operator Positions	2 to 12	2, 3, 4					
Operating Temperature	Operating Temperature -20 to +50°C (no freezing)						
Storage Temperature	perature -40 to +80°C (no freezing)						
Operating Humidity	45 to +85% RH (no condensation)						
Insulation Resistance	100 MΩ (500V DC megger)						
Dielectric Strength	2500V AC, 1 minute (between live a	nd dead parts)					
Mechanical Life	1 to 3 decks: 500,000 operations 4 to 6 decks: 200,000 operations						
Electrical Life	200,000 operations minimum						
Degree of Protection	ACSNO, ACSSO: IP65 (IEC 60529) ACSNK, ACSSK: IP54 (IEC 60529) UCS: IP40 (IEC 60529)						
Weight (approx.) 319g (ACSNO-663-S2B)							

CSB Contact Block

The CSB contact block contains two poles of double-break contacts. The contacts are operated by a cam designed to perform a required contact operation. Up to six contact blocks can be mounted on a maintained-action operator base, and up to three contact blocks on a spring return operator base.






Cam Switches

① M	odel	② Contact			@ Carina		⑦ Contact		<u> </u>	
ø30 Series	ø25 Series	Block Decks	③ Positions	4 Angle	⑤ Spring Return	⑥ Handle	Arrangement	Nameplate	& Pilot Lights	
ACSN0	ACSS0								ghts	
(Photo: ACSNO with Y2 ha		Maintained: 1 to 6 decks Spring return: 1 to 3 decks	Maintained: 2 to 12 positions Spring return: 2 to 4 positions	Maintained: 30°, 45°, 60°, 90° Spring return: 45° only	Spring return from right Spring return from left Spring return two-way	Y2, S2, P2, 25S2 (25S2 is for ACSSO only) (one specified handle supplied) (Note 1)		See B-361	APEM Switches & Pilot Lights Control Boxes	
ACSNK	ACSSK							(ordered	Emergency Stop Switches	
AHE	H2 Handle Key (black)	-			Spring return			separately)	Enabling Switches	
£ -0	(Diack)	Maintained: 1 to 6 decks	Maintained: 2 to 8 positions	Maintained: 45°, 90°	from right Spring return	Two standard keys are supplied.	See B-362 to		Safety Products	
Standard Key (2 keys supplied)		Spring return: 1 to 3 decks	Spring return: 2 to 4 positions	Spring return: fi 45° only S	from left Spring return two-way	when the H2 key	B-364.		Explosion Proof	
		1 to 3 decks	2 to 4 positions						Terminal Blocks	
									Relays & Sockets	
UCSQ0	(Enclosed)	_							Circuit Protectors	
CHIL		Maintainad	Maintained	Spring return			Type CQ See B-361	Power Supplies		
		Maintained: Maintained: 1 to 6 decks 2 to 12 position							LED Illumination	
4		Spring return: 1 to 3 decks	Spring return: 2 to 4 positions	Spring return: 45° only	from left Spring return			(ordered separately)	Controllers	
					two-way				Operator Interfaces	
(Photo: With Y2 handle) UCSQM	(Enclosed)					Y2, S2, P2 (one specified handle			Sensors	
UUSQIVI	Indicator					supplied)			AUTO-ID	
	Left: Green Right: Red	Carina return	Carina ratura	Carina return	Carina ratura		C1007 C1008 C1009 C1010 C1018 C2006	Type CQM See B-361		
1000	1.60	Left	Spring return: 1 to 3 decks	Spring return: 3 positions	Spring return: 45° only	Spring return two-way		C2007 C2021 See B-362 to	(ordered separately)	Flush Silhouette
							B-364.	συμαιαισιή)	ø16	
	Spring Return 2-way								ø22	

Note 1: The applicable handle for ACSSO is 25S2 only. The applicable handle for ACSNO is Y2, S2, and P2 only.



UCSQ0 UCSQM **Panel Cut-out** Panel Thickness 7.0 max. Panel Thickness 7.0 max. 4-M4 Screw 0 M3.5 Terminal M3.5 Terminal Screw 48 12N+9 □70 Spring Return: 31 Maintained: 29 N: Number of Contact Blocks N: Number of Contact Blocks . Minimum horizontal/vertical mounting centers With P2 handle: 125 With other handles: 70

With P2 handle: 125 With other handles: 70

Control Boxes

Emergency
Stop Switches

Enabling
Switches

Safety Products

Explosion Proof

Terminal Blocks

Relays & Sockets

Circuit
Protectors

Power Supplies

LED Illumination

Operator Interfaces

> Sensors AUTO-ID

Flush Silhouette

ø16

ø22

Miniature

Pilot Lights

TWND ARN

Ordering Information

When ordering, specify items \odot through \oslash as the designation example below.

MILLE	when ordering, specify items ψ unrough ψ as the designation example below.											
	1	2	3	4		6		8				
	Model	Contact Block Decks	Positions	Angle	Spring Return	Handle	Key irremovable position	Circuit No.				

	(1)	2		3		4		(5)		6	7)	(8)
	U	Decks	Code	Positions	Code	Angle	Code	Return	Code	0	V	8
	ACSN0	1 deck	1	2 positions	2	30°	3	Spring return	R0	(Code)	For ACSNK/	For standard contact
ıl	ACSNK	2 decks	2	3 positions	3	45°	4	from left		Y2, S2, P2, H2,	ACSSK, specify	configurations, use
	ACSS0	3 decks	3	4 positions	4	60°	6	Spring return	0R	25S2	the code(s) of	designation code on
۱	ACSSK	4 decks	4	5 positions	5	90°	9	from right		(Color)	irremovable	B-362 to B-364.
	UCSQ0	5 decks	5	6 positions	6			Spring return	RR	B: Black	position(s) in	For custom contact
	UCSQM	6 decks	6	7 positions	7			two-way		See table below.	numerical order.	configurations, use
.				8 positions	8							the Custom Contact
				9 positions	9							Configuration
-				10 positions	10							Specification Sheet on
				11 positions	11							B-365.
-				12 positions	12							
		Spring retu		Spring return:		ACSNK/ACS		Spring return		25S2 is for ACSS0		
•		1 to 3 deck	s only	2 to 4 position	is only	45° and 90°	•	is required onl	y for	only.		
						Spring return	1:	spring return.		Chandand ACCNIV/		
						45° only				Standard ACSNK/		
-										ACSSK: no specification		
										required		
- [точиной		

Designation Example

 $\frac{\text{ACSNO}}{\textcircled{1}} \cdot \frac{\textbf{2}}{\textcircled{2}} \cdot \frac{\textbf{3}}{\textcircled{3}} \cdot \frac{\textbf{4}}{\textcircled{5}} \cdot \frac{\textbf{RR}}{\textcircled{6}} \cdot \frac{\textbf{Y2B}}{\textcircled{6}} \cdot \frac{\textbf{MAU} \cdot \underline{\textbf{C2006}}}{\textcircled{8}} \cdot \textbf{ZT2}$

- When a special contact configuration is required, specify the contact configuration using the Custom Contact Configuration Specification Sheet on B-365.
- 2. A specified handle is attached.
- Accessories such as nameplates and jumpers are separately ordered.
- 4. The key of the key operated cam switch is removable at every position unless otherwise specified. The key is irremovable at return position. The return and irremovable positions must be specified in Part No. Positions at 180° from irremovable positions are also irremovable.

Example: 4-positions, spring return from right, irremovable at positions 3 and 4 $\,$

ACSNK-3440R-134-C3012

Handle Designation Code

Shape	Code	Color	Applicable Cam Switch
ø30 Y Handle 30 22 19	Y2		ACSNO UCSQO
ø30 S Handle	S2		UCSQM
ø25 S Handle 25.6 20 30	25S2	B: black	ACSS0
ø30 P Handle 30 \$\sqrt{50}\$	P2		ACSNO UCSQO UCSQM
Key Handle	H2		ACSNK ACSSK

Spring Return Operation

Available combinations of operator positions, angles, and return directions are listed in the table below

Available Combinations of Operator positions, angles, and return directions are listed in the table below.													
Positions	2-po:	sition		3-position		4-po:	3-position						
	From Left	From Right	From Left	From Right	Two-way	From Left	From Right	Two-way					
Return Direction	1_2	2 1 2 3 1 2 3 1		1 2 3	1 3 4	2 3 4	1 2 3						
3 4 5 Codes	24R0	240R	34R0	340R	34RR	44R0	440R	34RR					
Applicable Cam Switches		·	ACSNO, AC	SSO, ACSNK, ACS	SK, UCSQO			UCSQM					
Contact Block Decks		1 to 3 decks											

Note: Maintained do not require spring return code ⑤.

Accessories and Maintenance Parts

Shape	Material	Part No.	Ordering No.	Package Quantity	Remarks
Jumper CJ-1	Metal	CJ-1	CJ-1PN10	10	For connecting terminals of adjoining contact blocks
CJ-2	(copper)	CJ-2	CJ-2PN10	10	For connecting terminals of the same contact block
Rubber Boot	Nitril rubber	CR-1	CR-1	1	For preventing ingress of dust into the contact blocks Not applicable for the UCSQO and UCSQM
Terminal Cover	Plastic	CS-VL2-13S	CS-VL2-13S	1	For 1 to 3 decks of contact blocks
CS-VL2-13S CS-VL2-46S Supplied with 2 self-tapping screws for mounting	(PPE)	CS-VL2-46S	CS-VL2-46S	1	For 4 to 6 decks of contact blocks

Shape	Material (Color)	Part No.	Ordering No.	Package Quantity
Ø30 Y Handle 30 22 19	Polybutylene terephthalate (Black)	CSH-YB	CSH-YB	1
Ø30 S Handle 30 20 30	Polybutylene terephthalate (Black)	CSH-SB	CSH-SB	1
Ø25 S Handle 25.6 20 30	Phenol resin (Black)	CSH-25SB	CSH-25SB	1
Ø30 P Handle 30 50	Phenol resin (Black)	CSH-PB	CSH-PB	1
Key Handle	Phenol resin (Black)	CSH-H2B	CSH-H2B	1
Spare Keys	Metal (brass nickel-plated)	CSH-K301	CSH-K301PN02	2
Handle Shaft	Polyamide	CS-HF2C	CS-HF2CPN05	5
Handle Screw	For Y, ø30 S, and ø25 S handles M3 × 12	CS-SCW-M3-12	CS-SCW-M3-12PN10	10
Handle Screw	For P and F handles M3 × 25	CS-SCW-M3-25	CS-SCW-M3-25PN10	10

Switches & Pilot Lights

Control Boxes

Emergency Stop Switches

Enabling Switches

Explosion Proof

Terminal Blocks

Relays & Sockets

Circuit Protectors

Power Supplies

LED Illumination

Controllers

Operator Interfaces


Sensors

AUTO-ID


Instructions

Installing the Terminal Cover for the CS series Cam Switches


- Complete wiring before installing the terminal cover on the bottom plate of the contact block.
- The terminal cover has six holes. Of the four round holes at four corners, use two diagonal pair of holes to install the terminal cover. Either pair can be used.
- Insert the attached self-tapping screws into the pair of holes and tighten the screws to a torque of 0.8 to 1.0 N·m.
- For 1 through 3 decks of contact blocks, use terminal cover CS-VL2-13S.
- For 4 through 6 decks of contact blocks, use terminal cover CS-VL2-46S.
- The CS-VL2-46S consists of the CS-VL2-13S and a terminal cover for the fourth through sixth decks. Combine the two parts together as shown. Note that once combined, the two parts cannot be separated.




Minimum Mounting Centers for Installing the Terminal Cover




 Although the minimum mounting centers are 100 mm horizontally and 70 mm vertically, determine the mounting centers in consideration of convenience of wiring. For the P2 handle, the minimum mounting centers are 125 mm horizontally and vertically.



For 4 through 6 decks of contact blocks (CS-VL2-46S)





All dimensions in mm.

Safety Products

Control Boxes

Emergency

Enabling Switches

Stop Switches

Explosion Proof

Terminal Blocks

Relays & Sockets

Circuit

Protectors

Power Supplies

LED Illumination

Controllers Operator

Interfaces Sensors

AUTO-ID

Flush Silhouette

ø16

ø22

Miniature

Pilot Lights

TWN

ARN

C6

Accessories and Maintenance Parts

For ø25 / ø30 Cam Switches

	Shape	Panel-cut Size	Material	Part No.	Ordering No.	Package Quantity	Remarks
Tool	Locking Ring Wrench (B) (A)	ø25 ø30	Nitril rubber (black)	OR-12	OR-12	1	Used to tighten the locking ring when installing the ø30 or ø25 switch onto a panel. Series 90 ø30 Series
Anti-ro		ø25	Metal	0GL-21	0GL-21PN10		Used to prevent the operator from turning. Generally used when using no nameplates on selector switches
Anti-rotation Ring		ø30	(diecast) (zinc-plated)	0GL-11	0GL-11PN10	10	Used to prevent the operator from turning. Generally used when using no nameplates on selector switches and selector pushbuttons. 1 piece included with cam switches
		ø25	Nitril rubber (black)	0BS-13B	OBS-13BPN05		Used to plug unused Ø25.5mm mounting holes. Protection degree: IP65 (round hole) IP65 (round hole)
		V 23	Nitril rubber (gray)	0BS-13	OBS-13PN05	5	• IP40 (anti-rotation)
		ø30	Nitril rubber (black)	0B-13B	0B-13BPN05	J	Used to plug unused ø30mm mounting holes. Protection degree: IP40
Mounti		3 00	Nitril rubber (gray)	OB-13	0B-13PN05		030 034 034
Mounting Plug	Plastic	ø30	Plug: ABS, gray Gasket: Chloroprene rubber		0BP-11	1	Tightening torque: 1.2 N·m. Degree of protection: IP65 (when hole for antirotation is not available) Locking ring provided Gasket M30 ^{P1.5} screw Locking ring
	Metal	ø30	Plug: Zinc diecast chrome-plated Gasket: Chloroprene rubber Locking ring: Zinc diecast	OB-11	0B-11	1	Tightening torque: 1.2 N·m. Degree of protection: IP65 (when hole for antirotation is not available) Locking ring provided Cocking ring
Bezel	Flush	ø25	Metal (Zinc diecast chrome-plated)	0G-22	0G-22PN02	2	• ø30 (ø21) H9
zel		ø30	Metal (Zinc diecast chrome-plated)	0G-11	0G-11PN02	2	• Cannot used with monolevers • ø35 H9
	3.0mm thick	ø25	Synthetic soft vinyl	0W-22	OW-22PN10	10	• ø33.8 (ø25.5) H3
Rubber		ø30	Symmono soft villyl	0W-12	OW-12PN10	10	• ø39 (ø29.5) H3
Rubber washer	1.5mm thick	ø25			OW-21PN10	10	• ø33.8 (ø25.5) H1.5
	O	ø30	Synthetic soft vinyl	OW-11	OW-11PN10	10	• ø39 (ø29.5) H1.5

APEM

Switches &

Control Boxes

Emergency Stop Switches Enabling Switches

Safety Products

Explosion Proof

Terminal Blocks

Relays & Sockets

Circuit Protectors

Power Supplies

LED Illumination

Controllers

Operator Interfaces

Sensors

AUTO-ID

Flush Silhouette

ø16

ø22

ø30

Miniature

Pilot Lights

TWN

TWND

ARN

CS

ADMICO

Control Boxes

Emergency
Stop Switches

Enabling
Switches

Safety Products

Explosion Proof

Terminal Blocks

Relays & Sockets

Circuit
Protectors

Power Supplies

LED Illumination

Controllers

Sensors AUTO-ID

Flush Silhouette

ø16 ø22

Miniature Pilot Lights

Nameplates

	Item	Legend	Material	Part No.	Ordering No.	Package Quantity	Dimensions (mm)	Applicable Unit	
		Diagle		00.0	CQ-0	1	With adhesive tapes on the back		
<u></u>	00	Blank	Aluminium 0.5 mm thick	CQ-0	CQ-0PN10	10	2-03.5	UCSQ0	
& is	CQ	With Legend (Legend Codes	White letters on black background	CQ-□	CQ-□	1		Cam Switch	
cy es eg		31 and 53 only)		CQ-LI	CQ-□PN10	10	<u>Ø13</u>		
ts		Blank		CQM-0	CQM-0	1	With adhesive tapes on the back		
of S	CQM	Dialik	Aluminium 0.5 mm thick	CQIVI-U	CQM-0PN10	10		UCSQM Cam Switch	
ts	CQIVI	With Legend (Legend Code	White letters on black background	CQM-□	CQM-□	1	2-03.5		
it 's 's		31 only)		OQW-L	CQM-□PN10	10	40		
n		Blank		CQN-0	CQN-0	1	With adhesive tapes on the back	ACSNO, ACSNK Cam Switches ø30 mm Selector Switches	
rs Or es	CQN	Dialik	Aluminium 0.5 mm thick	CQN-0	CQN-0PN10	10	(030.5)		
rs	CUN	With Legend (Legend Codes	White letters on black background	CQN-□	CQN-□	1			
D —		31, 35, and 53 only)		CQN-L	CQN-□PN10	10	□64		
e e		Blank		CQS-0	CQS-0	1	With adhesive tapes on the back		
6 2	CQS	DIATIK	Aluminium 0.5 mm thick	CQS-0	CQS-0PN10	10		ACSSO, ACSSK Cam Switches	
0	UUU	With Legend	White letters on black background	CQS-□	CQS-□	1		ø25 mm Selector Switches	
re — ts		(Legend Code 53 only)		UQ3-LI	CQS-□PN10	10	_ □64 >		

 $[\]bullet$ Specify a legend code in place of \square in the Ordering No.

Legends

TWN	- 3	_
	Code	Legend
TWND	0	(blank)
	1	ON
ARN	2	0FF
CS	3	START
	4	STOP STOP
ARN/CS	31	OFF-ON
	35	HAND-AUTO
	53	HAND-OFF-AUTO

\triangle


Safety Precautions

- Turn off the power before starting installation, removal, wiring, maintenance, and inspection of the products. Failure to turn power off may cause electrical shocks or fire hazard.
- To avoid a burn on your hand, use the lamp holder tool when replacing lamps.
- For wiring, use wires of a proper size to meet the voltage and current requirements. Tighten the M3.5 terminal screws to a tightening torque of 1.0 to 1.3 N·m. Failure to tighten terminal screws may cause overheat and fire.



Standard Contact Configurations

- The following table lists 76 standard contact configurations for easy designation of required cam switch operation.
- When other contact configurations are required, specify the number of contact block decks, operator positions, angles, and contact operation using the Custom Contact Configuration Specification Sheet on B-358.




Symbol	Contact Operation
•	Contacts closed.
_	Contacts remain closed between two operator positions.
##	Overlapping Contacts Contacts of different decks are both closed at one point while the handle is turned to the next position.
0::::•	Residual Contacts When the handle is returned to the center, the contacts remain closed. The contacts are opened when the handle is turned to the opposite direction.

The 76 standard contact configurations are listed in the order of the circuit number.


Same Circuits

Shown in the following examples, circuits of Fig. 1 and Fig. 2 have the same functions. When ordering, examine the standard contact configurations. Your requirements may be satisfied simply by changing external wiring of the standard contact configurations.



Terminal Numbers

 The terminal numbers on the contact blocks correspond with the numbers shown in the chart as shown below.



APEM

Switches &

Control Boxes

Emergency Stop Switches Enabling

Switches
Safety Products

Explosion Proof

Terminal Blocks
Relays & Sockets

Circuit

Protectors

Power Supplies

LED Illumination

Controllers

Operator Interfaces

Sensors

AUTO-ID

Listing Order of the Table

Listing order of the Table				
	St	tandard Contact Configuration Cha	art	
1 2 9 C1001	1 2 9 C1002	1 2 4 OR C1003	1 2 4 OR C1004	1 3 4 C1005
3 - 4 4 1 - 2 1 2	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$		3	3 - 4 1 - 2 2 1 2 3
1 3 4 C1006	1 3 4 RR C1007	1 3 4 RR C1008	1 3 4 RR C1009	1 3 4 RR C1010
3 4 2 1 2 3	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	$ \begin{array}{c ccccccccccccccccccccccccccccccccccc$
1 4 4 C1011	1 2 9 C1013	1 2 9 C1014	1 2 4 OR C1015	1 3 4 C1016
3 4 4 1 2 3 4	3 4 1 2	3 4 1 2	3 4 1 2 1 + 2	3 4 2 1 2 3
1 2 4 C1017	1 3 4 RR C1018	1 2 6 C1019		
3 4 4 1 2 1 2	$ \begin{array}{cccccccccccccccccccccccccccccccccccc$	3 4 1 2		
2 2 9 C2001	2 2 9 C2002	2 3 4 C2003	2 3 4 C2004	2 3 4 C2005
7 ————————————————————————————————————	7 8 5 6 3 4 1 2	7	7	7 8 6 6 3 4 1 2 1 2 3

Flush Silhouette

ø16

ø22

ø30

Miniature

Pilot Lights

TWND ARN CS

Control Boxes

Emergency
Stop Switches
Enabling
Switches
Safety Products

Explosion Proof
Terminal Blocks
Relays & Sockets
Circuit
Protectors
Power Supplies

LED Illumination
Controllers
Operator
Interfaces
Sensors

AUTO-ID

Flush Silhouette


ø16 ø22

Miniature Pilot Lights


TWND
ARN
CS

Cam Switches

,	0.0.4.PD 00000	0.0.4.DD 00007	0.4.4	0.4.4	0.4.0
ł	2 3 4 RR C2006	2 3 4 RR C2007	2 4 4 C2008	2 4 4 C2009	2 4 9 C2011 7 8
	7 - 8 6	7 8 6	7 8 6	7 8 6	5 6
	3 4 4 2	3 4 2	3 4 1 2	3 4 2	1 2
	1 → 2 ← 3	1 → 2 ← 3	1 2 3 4	1 2 3 4	1 2 3 4 (0) (R) (S) (T)
	2 2 9 C2014	2 2 9 C2015	2 3 4 C2016	2 3 4 C2017	
1	7 - 8 5 - 6	7 — 8	7 - 8 8 5 - 6	7 8 8	
& S	3 4	5 6 3 4	3 4 4	3 4 1 2	
s	1 2	1 — 2	1 2 3	1 2 3	
y s	2 3 4 C2019	2 3 4 C2020	2 3 4 RR C2021	2 4 4 C2022	
g	7 + 8	7 - 8	7 8 8 5 6	7 - 8	
s_ s	5 6 6 4	5 6 3 4	3 4	5 6 3 4	
of	1 2 3	1 2 3	$ \begin{array}{c c} 1 & \hline & \downarrow \\ 1 & \hline & 2 \\ 1 & \hline & 2 \end{array} $	1 2 3 4	
- j			2 5 3 C2027	2 3 6 C2028	2 3 6 C2029
s _			7 + 8	7 — 8	7 - 8
s — it			5 6 4	5 6 4	5 6 4
s			1 2 3 4 5	1 2 3	1 - 2 1 2 3 (R) (S) (T)
s —	3 2 9 C3001	3 3 4 C3002	3 5 4 C3003	3 6 4 C3004	(R) (S) (T) 3 3 4 C3005
n _	11 — 12	11 - 12	11 12	11 12	11 - 12
s _	9 — 10 7 — 8	9 10 7	9 10 8	9 10 7	9 10 7 8
r s_	5 6	5 6	5 6 4	5 6	5 6 4
s	1 2	3 4 2	1 + 2	1 + 2	1 2
_	1 2	1 2 3	1 2 3 4 5	1 2 3 4 5 6	1 2 3
_	3 4 9 C3008	3 4 9 C3009	3 2 9 C3010	3 3 4 C3011	3 4 4 C3012
_	9 10 7 8	11 12 10	11 — 12 9 — 10	11 12 12 10	11 12 10
e	5 6	7 8 6	7 8 6	7 8 5 6	7 8 6
6	3 4 2	3 4 2	3 4 1 2	3 4 1 2	3 4 2
2	1 2 3 4 (0) (RS) (ST) (TR)	1 2 3 4	1 2	1 2 3	1 2 3 4
0	3 6 3 C3013	3 3 6 C3014	3 6 6 C3015	3 5 3 C3016	3 4 4 C3017
e	11 12 10	11 12 10	11 12 12	11 12 10	11 12 12
_ s	7 8 6	7 8 8	7 8 6	7 8 6	7 8 5 6
-	3 4	3 4	3 4 4	3 4	3 4
	1 2 3 4 5 6	1	1 2 3 4 5 6	1 2 3 4 5	1 2 3 4
,	3 3 6 C3018		4 4 4 C4001	4 8 4 C4002	4 4 9 C4003
_	, 		15 16	15 16	15 16
_ N	11 12 10		13 14 12	13 14 12	11 12
-	7 8 8		9 10 7 8	9 10 7 8	9 10 7 8
	3 4 4		5 6 4	5 6 3 4	5 6 4
	1 2 3		1 2 3 4	1 2 3 4 5 6 7 8	1 2 3 4 (0) (R) (S) (T)
	4 2 4 C4004	4 2 9 C4005	4 2 9 C4006	4 4 9 C4007	(0) (R) (S) (T) 4 3 4 C4008
	15 — 16	15 16	15 — 16	15 16	15 + 16
	13 — 14	13 — 14	13 — 14	13 14 12	13 14
	9 10 7 8	9 10 7 8	9 10 7 8	9 10 7 8	9 10 7
	5 6	5 6	5 — 6	5 6 3	5 6
	3 • 4 1 <u>•</u> 2	3 4 4 2	3 4 4 2	1 2	3 4 2
	1 2	1 2	1 2	1 2 3 4 (0) (R) (S) (T)	1 2 3



Application Examples (Voltmeter and Ammeter Circuits)



APEM

Control Boxes

Emergency Stop Switches Enabling Switches

Safety Products

Explosion Proof

Terminal Blocks Relays & Sockets

Circuit

Protectors Power Supplies

LED Illumination

Controllers

Operator

Interfaces

Sensors

AUTO-ID

Flush Silhouette

ø16

ø22

Miniature

Pilot Lights

TWN

TWND

ARN

CS

Control Boxes

Safety Products

Explosion Proof

Terminal Blocks

Relays & Sockets

Power Supplies

LED Illumination

Flush Silhouette

ø16 ø22

Miniature Pilot Lights

TWND
ARN
CS

Operator Interfaces Sensors

Circuit

Protectors

Emergency

Enabling Switches


Cam Switches

Custom Contact Configurations Specification Sheet

- The preceding pages provide 68 standard contact configurations.
 When other contact configurations are required, specify the number of contact block decks, operator positions, angles, and contact operation using the Custom Contact Configuration Specification Sheet shown below.
- For available number of contact blocks and operator positions, see the Ordering Information on B-357.

1. Specify operator positions

Indicate the operator positions starting at the first position. When spring return operation is required, mark an arrow between two operator positions to indicate the spring return direction.



2. Specify contact operation at each operator position Indicate the required operation of all contacts at each operator position using the following symbols.

Symbol	Contact Operation
•	Contacts closed.
	Contacts remain closed between two operator positions.
++	Overlapping Contacts Contacts of different decks are both closed at one point while the handle is turned to the next position. Overlapping contacts are not available for handle angles of 30° and 45°.
O::::•	Residual Contacts When the handle is returned to the center, the contacts remain closed. The contacts are opened when the handle is turned to the opposite direction.

 One deck of contact block contains two poles of contacts and four terminals. When the handle is made to turn 180° or more, special attention is needed. Since one cam operates the two poles of contacts on opposite positions, the same contact operation repeats on the other pole of contacts when the handle is turned 180°. When different contact operation is needed for handle angles of 180° or more, use another deck of contact block.

		CS Se	ries Ca	m Switc	h Custo	m Conta	act Con	figuratio	n Speci	fication	Sheet			
Part No.:		- J II - J	Decks	3 Posi	tions	4 Angle	- 11 - 15 - 11	-	¬ turn	6 Handl	e - ¬	Quant	ity:	
Deck	Terminal No.					Contac	t Confi	guration	Chart					Terminal No.
Deck 6	23	+	-	+	-	-	-	-	-	-	-	+	-	- 24
Deck o	21	-	-		-	-	-	-	-	-	-	•		- 22
Deck 5	19	-	-	-	-	-	-	-	-	-	-	+		- 20
DOOK O	17	-	•		•	-	-	•	•		-		-	- 18
Deck 4	15	+	-		-		-		-		-			- 16
DOOK 1	13	-	<u></u>		_	•	-	-	-		-			- 14
Deck 3	11	-	-		-		-	-	-		-			- 12
DOUN O	9	-	-	•	-	•	-	•			-			- 10
Deck 2	7	-	-		-		-	-	-		-			- 8
	5	-	<u></u>	-	<u></u>		<u></u>	<u></u>	_		-			- 6
Deck 1	3	-	-		-		-		-		-			- 4
_ 30	1	+	<u></u>	<u></u>	-	+	-	<u></u>	<u></u>	-	<u></u>	+	—	- 2
Angle														
Positions Spring Retur	'n	1	2	3	4	5	6	7	8	9	10	11	12	

SAPEN01A_B ARN/CS_August 2022



Ordering Terms and Conditions

Thank you for using IDEC Products.

By purchasing products listed in our catalogs, datasheets, and the like (hereinafter referred to as "Catalogs") you agree to be bound by these terms and conditions. Please read and agree to the terms and conditions before placing your order.

1. Notes on contents of Catalogs

- (1) Rated values, performance values, and specification values of IDEC products listed in this Catalog are values acquired under respective conditions in independent testing, and do not guarantee values gained in combined conditions.
 - Also, durability varies depending on the usage environment and usage conditions.
- (2) Reference data and reference values listed in Catalogs are for reference purposes only, and do not guarantee that the product will always operate appropriately in that range.
- (3) The specifications / appearance and accessories of IDEC products listed in Catalogs are subject to change or termination of sales without notice, for improvement or other reasons.
- (4) The content of Catalogs is subject to change without notice.

2. Note on applications

- (1) If using IDEC products in combination with other products, confirm the applicable laws / regulations and standards.
 - Also, confirm that IDEC products are compatible with your systems, machines, devices, and the like by using under the actual conditions. IDEC shall bear no liability whatsoever regarding the compatibility with IDEC products.
- (2) The usage examples and application examples listed in Catalogs are for reference purposes only. Therefore, when introducing a product, confirm the performance and safety of the instruments, devices, and the like before use. Furthermore, regarding these examples, IDEC does not grant license to use IDEC products to you, and IDEC offers no warranties regarding the ownership of intellectual property rights or non-infringement upon the intellectual property rights of third parties.
- (3) When using IDEC products, be cautious when implementing the following.
 - i. Use of IDEC products with sufficient allowance for rating and performance
 - Safety design, including redundant design and malfunction prevention design that prevents other danger and damage even in the event that an IDEC product fails
 - Wiring and installation that ensures the IDEC product used in your system, machine, device, or the like can perform and function according to its specifications
- (4) Continuing to use an IDEC product even after the performance has deteriorated can result in abnormal heat, smoke, fires, and the like due to insulation deterioration or the like. Perform periodic maintenance for IDEC products and the systems, machines, devices, and the like in which they are used.
- (5) IDEC products are developed and manufactured as general-purpose products for general industrial products. They are not intended for use in the following applications, and in the event that you use an IDEC product for these applications, unless otherwise agreed upon between you and IDEC, IDEC shall provide no guarantees whatsoever regarding IDEC products.
 - i. Use in applications that require a high degree of safety, including nuclear power control equipment, transportation equipment (railroads / airplanes / ships / vehicles / vehicle instruments, etc.), equipment for use in outer space, elevating equipment, medical instruments, safety devices, or any other equipment, instruments, or the like that could endanger life or human health
 - Use in applications that require a high degree of reliability, such as provision systems for gas / waterworks / electricity, etc., systems that operate continuously for 24 hours, and settlement systems
 - iiii. Use in applications where the product may be handled or used deviating from the specifications or conditions / environment listed in the Catalogs, such as equipment used outdoors or applications in environments subject to chemical pollution or electromagnetic interference If you would like to use IDEC products in the above applications, be sure to consult with an IDEC sales representative.

3. Inspections

We ask that you implement inspections for IDEC products you purchase without delay, as well as thoroughly keep in mind management/maintenance regarding handling of the product before and during the inspection.

4. Warranty

(1) Warranty period

The warranty period for IDEC products shall be one (1) year after purchase or delivery to the specified location. However, this shall not apply in cases where there is a different specification in the Catalogs or there is another agreement in place between you and IDEC.

(2) Warranty scope

Should a failure occur in an IDEC product during the above warranty period for reasons attributable to IDEC, then IDEC shall replace or repair that product, free of charge, at the purchase location / delivery location of the product, or an IDEC service base. However, failures caused by the following reasons shall be deemed outside the scope of this warranty.

- i. The product was handled or used deviating from the conditions / environment listed in the Catalogs
- ii. The failure was caused by reasons other than an IDEC product
- iii. Modification or repair was performed by a party other than IDEC
- iv. The failure was caused by a software program of a party other than IDEC
- v. The product was used outside of its original purpose
- Replacement of maintenance parts, installation of accessories, or the like was not performed properly in accordance with the user's manual and Catalogs
- vii. The failure could not have been predicted with the scientific and technical standards at the time when the product was shipped from IDFC
- viii. The failure was due to other causes not attributable to IDEC (including cases of force majeure such as natural disasters and other disasters)
 Furthermore, the warranty described here refers to a warranty on the IDEC product as a unit, and damages induced by the failure of an IDEC product are excluded from this warranty.

5. Limitation of liability

The warranty listed in this Agreement is the full and complete warranty for IDEC products, and IDEC shall bear no liability whatsoever regarding special damages, indirect damages, incidental damages, or passive damages that occurred due to an IDEC product.

6. Service scope

The prices of IDEC products do not include the cost of services, such as dispatching technicians. Therefore, separate fees are required in the following cases.

- (1) Instructions for installation / adjustment and accompaniment at test operation (including creating application software and testing operation, etc.)
- (2) Maintenance inspections, adjustments, and repairs
- (3) Technical instructions and technical training
- (4) Product tests or inspections specified by you

The above content assumes transactions and usage within your region. Please consult with an IDEC sales representative regarding transactions and usage outside of your region. Also, IDEC provides no guarantees whatsoever regarding IDEC products sold outside your region.

IDEC CORPORATION

ad Office 6-64, Nishi-Miyahara-2-Chome, Yodogawa-ku, Osaka 532-0004, Japan

IDEC (Shanghai) Corporation

Japan IDEC Corporation

USA EMEA IDEC Corporation APEM SAS Singapore IDE Thailand IDE India IDE

IDEC Izumi Asia Pte. Ltd.
IDEC Asia (Thailand) Co., Ltd.
IDEC Controls India Private Ltd.

China Taiwan

IDEC Izumi (H.K.) Co., Ltd.

IDEC Taiwan Corporation

idiwan ibeo idiwan oorpi



☐ www.idec.com